How do I activate/deactivate Child Lock function on the Double Power Point?

Home Owner · https://pixiepartners.com.au/support-docs/how-do-i-activate-deactivate-child-lock-function-on-the-double-power-point/

The Child Lock function can be turned on and off from the PIXIE or PIXIE Plus app by selecting the device in the app and selecting the child lock functionalitynnIt is also possible to depress both the left hand and right hand button at the same time for approx. 10-12 seconds. When Child Lock is activated these 2 buttons will flash white for a few seconds as confirmation.