My lights are dimmed really low, how do I make them immediately go to full?

Dimmers · https://pixiepartners.com.au/support-docs/my-lights-are-dimmed-really-low-how-do-i-make-them-immediately-go-to-full/

From the dimmer on the wall plate, press the dimmer button twice quickly.nnAll lights connected to that dimmer will instantly go to 100% light output.

You can also hold your finger on the button and your lights will slowly dim up or dim down. If they start to dim up, release the button, and press and hold it again to dim the lights up.