

PIXIE Multifunction Controller

#SMFBTAS



▶ Basic operation

- In Mimic mode, mimics button presses of Master devices
- In scene mode single click and / or double click recalls paired scene.
- 4 clicks manual pairing
- 5 clicks change LED colour
- 9 clicks reset device

▶ Applications

Perfect for 2-way, 3-way up to 8-way control of devices or groups. Welcome Home / Goodbye Scene recall etc.

▶ Whats in the box

1 x Multifunction controller, 1 x silicone adaptor/spacer, 3 x switch caps, installation instructions

▶ Accessories

PIXIE Ambience wall and faceplates in White/Grey/Black



#SMFBTAS

PIXIE Multifunction Controller



Multifunction secondary devices which can be paired to operate with any Master PIXIE devices in either MIMC mode or SCENE mode. Control any PIXIE device, groups or scene from anywhere in the home with this device. Comes with Bluetooth Mesh Technology.

Features

- Requires Active + Neutral connection from anywhere to operate
- Requires at least 1 PIXIE Master device to provide function
- Fit most branded switch plates and PIXIE Ambience plates
- Mimic Mode - mimc the control of any master device paired
- Scene Mode - single click and double click scene recall functions
- LED indicator can be changed colour (via the PIXIE Apps and button clicks) with choices between blue and orange for easier identification once installed
- Generation 3 product compatible with Gen 1 and Gen 2 products

Electrical

Power Supply	220-240VAC
Min/ Max loads*	No connected load
Operating ambient min/max (°C)	0 to 40°
Typical wireless range	15 metres typical indoors **
IP Rating	IP20

*Subject to product capability, this size load may require the inclusion of the LOAD capacitor included in the product carton.
** Depending on building materials and construction.



SCAN ME

Download the PIXIE and
PIXIE PLUS Apps



PIXIE multi function controller

#SMFBTAS



Related products

PIXIE Smart Dimmer
SDD300BTAM (G3)



PIXIE Smart Dimmer
SDD350BT (G2)





PIXIE 600W Switch
#SWL600BTAM



PIXIE Timer Switch
#STS600BTAM



Wiring Diagram



Optional BP (Bell Press version - SMFBTAS-BP) accepts a bell press input from a bell-press mech or dry contact/volt free input from a 3rd party system to activate device. Bell press operation is identical to the button operation as described above.

PIXIE fits in

PIXIE fits in to a huge range of Australian wall plates



SCAN ME



SCAN ME

Download the PIXIE and
PIXIE PLUS Apps

